

PoE + POWERCELL

**PoE+ 802.3at
MODEL 12AT -PASSIVE**

**MODEL 12ATA -ACTIVE
(power negotiation)**

**54vdc Pins 4,5 -
Pins 7,8+**

30W 802.3at/POE+ equivalent for Cisco Access Points -For Aironet AP2800/3800 use model 12ATA

TROUBLE SHOOTING

1. Verify that the battery cables are connected to the terminals. The top black wire to the black (-) and the bottom wire which is the fuse holder to the red (+), verify the cables are securely connected.

2. Verify to make sure the 3-amp fuse is in good condition, remove the top layer foam, remove the top cover of fuse holder and verify that the fuse has not been blown. If so, replace it with the correct fuse.

If you are still having issues, try charging the battery for a couple of hours. The light on the charger will be red if it

Note: Never store anything inside the unit.

This is **not** a water resistant device. Use only in a dry location.

3amp fuse inside.

Disconnect battery before shipping and storing.



Low Battery indicator

POWER SWITCH

CHARGE PORT

Charges only when power switch is in the off position